


1/8
NORMAL-FLOW HEAT EXCHANGER
JAVIER A. VALENZUELA
07389-00007


FIG. 1
PRIOR ART



2/8

NORMAL-FLOW HEAT EXCHANGER
JAVIER A. VALENZUELA
07389-00007


FIG.2




3/8

NORMAL-FLOW HEAT EXCHANGER
JAVIER A. VALENZUELA
07389-00007

FIG. 3




4/8
NORMAL-FLOW HEAT EXCHANGER
JAVIER A. VALENZUELA
07389-00007



5/8

NORMAL-FLOW HEAT EXCHANGER
JAVIER A. VALENZUELA
07389-00007


FIG.5



6/8

NORMAL-FLOW HEAT EXCHANGER
JAVIER A. VALENZUELA
07389-00007


FIG. 6



7/8

NORMAL-FLOW HEAT EXCHANGER
JAVIER A. VALENZUELA
07389-00007

FIG. 7



8/8

NORMAL-FLOW HEAT EXCHANGER
JAVIER A. VALENZUELA
07389-00007

FIG. 8

